



भाकृअनुप-राष्ट्रीय अंगूर अनुसंधान केन्द्र, पुणे  
ICAR-National Research Centre for Grapes, Pune



PT ID- NRL/PT-FV/2020/Grape-1

23-10-2020

**PRELIMINARY REPORT**

SCHEME: PESTICIDE RESIDUE IN GRAPE HOMOGENATE  
(ID: NRL/PT-FV/2020/Grape-1)



**PC-1027**

PROFICIENCY TESTING SCHEME  
CONDUCTED BY  
**National Referral Laboratory**  
**ICAR-National Research Centre for Grapes, Pune**  
**(An ISO/IEC-17043:2010 accredited PTP)**

|           | Prepared by                                       | Authorized by                                 |
|-----------|---|---|
| Signature |   |   |
| Name      | Dr. Ahammed Shabeer TP<br>(QM and PT Coordinator) | Dr. Kaushik Banerjee<br>(I/C, NRL, ICAR-NRCG) |

**भारतीय अंगूर अनुसंधान केन्द्र, पुणे**  
**ICAR-National Research Centre for Grapes, Pune**

---

**PT ID- NRL/PT-FV/2020/Grape-1**

Dear Participants,

We have compiled and evaluated the results submitted by you for the PT scheme **NRL/PT-FV/2020/Grape-1**. The report contains results of the participant laboratories along with the assigned values, standard deviation for proficiency assessment and preliminary z-score. If you find any deviation in the result submitted by your laboratory, please contact through E-mail at [apedanrlpt@gmail.com](mailto:apedanrlpt@gmail.com) or write to I/C NRL, ICAR-NRCG/PT-Coordinator, National Referral Laboratory, ICAR-National Research Centre for Grapes, Pune on or before 28-10-2020.

**Contact details:**

I/C NRL, NRCG/ PT-Coordinator

National Referral Laboratory

ICAR-National Research Centre for Grapes

Manjari Farm, Pune- 412307

E-mail: [apedanrlpt@gmail.com](mailto:apedanrlpt@gmail.com)

**भारतीय अंगूर अनुसंधान केन्द्र, पुणे**  
**ICAR-National Research Centre for Grapes, Pune**

**PT ID- NRL/PT-FV/2020/Grape-1**

**PRELIMINARY RESULTS**

**Table-1: Assigned Value and Standard Deviation for Proficiency Assessment (SDPA)**

| Sr. No. | Test parameter  | Assigned Value (mg/kg) | Standard Deviation for Proficiency Assessment (mg/kg) |
|---------|-----------------|------------------------|---|
| 1.      | Azoxystrobin    | 0.0514                 | 0.0077  |
| 2.      | Buprofezin      | 0.0683                 | 0.0102  |
| 3.      | Carbendazim     | 0.0492                 | 0.0074  |
| 4.      | Chlorpyrifos    | 0.129                  | 0.0194  |
| 5.      | Difenconazole   | 0.0550                 | 0.0083  |
| 6.      | Dimethomorph    | 0.0467                 | 0.0070  |
| 7.      | Fluopyram       | 0.0178                 | 0.0027  |
| 8.      | Fluxapyroxad    | 0.0196                 | 0.0029  |
| 9.      | Imidacloprid    | 0.0598                 | 0.0090  |
| 10.     | Kresoxim methyl | 0.0431                 | 0.0065  |
| 11.     | Mandipropamid   | 0.0652                 | 0.0098  |
| 12.     | Metrafenone     | 0.0190                 | 0.0029  |
| 13.     | Myclobutanil    | 0.0177                 | 0.0027  |
| 14.     | Pyraclostrobin  | 0.0161                 | 0.0024  |

**Note:**

The SDPA value calculated based on the participants' submitted results was found to be unreasonably low. Hence, SDPA of 15% of the assigned value was logically applied based on the PT provider's previous experience and expertise on z score calculations.

Considering the overall uncertainty of multiresidue analysis and proximity of the assigned value to the LOQ level, the z-scores were not calculated for the analytes viz. Chlormequat chloride, Spirotetramat, Spirotetramat enol and Thiamethoxam. These analytes were also not considered for false positives and false negatives.

**भारतीय अंगूर अनुसंधान केन्द्र, पुणे**  
**ICAR-National Research Centre for Grapes, Pune**

**Table 2a: Preliminary report showing analyte specific assigned values, robust standard deviation, reported concentration and z-score of the participating laboratories**

| Laboratory code | Aroxystrobin   |                  | Buprofezin     |                  | Carbendazim    |                  | Chlorpyriphos  |                  | Difenoconazole |                  | Dimethomorph   |                  | Fluopyram      |                  |
|-----------------|----------------|------------------|----------------|------------------|----------------|------------------|----------------|------------------|----------------|------------------|----------------|------------------|----------------|------------------|
|                 | Assigned value | Robust Std. Dev. |
|                 | Conc. mg/kg    | z-score          |
| Lab - 01        | 0.0521         | <b>0.09</b>      | 0.0712         | <b>0.28</b>      | 0.0486         | <b>-0.08</b>     | 0.133          | <b>0.20</b>      | 0.0550         | <b>0.00</b>      | 0.0464         | <b>-0.04</b>     | 0.0205         | <b>1.00</b>      |
| Lab - 02        | 0.0494         | <b>-0.26</b>     | 0.0668         | <b>-0.15</b>     | 0.0549         | <b>0.77</b>      | 0.128          | <b>-0.06</b>     | 0.0558         | <b>0.10</b>      | 0.0450         | <b>-0.24</b>     | 0.0189         | <b>0.41</b>      |
| Lab - 03        | 0.0515         | <b>0.01</b>      | 0.0685         | <b>0.02</b>      | 0.0562         | <b>0.95</b>      | 0.124          | <b>-0.26</b>     | 0.0561         | <b>0.13</b>      | 0.0470         | <b>0.04</b>      | 0.0180         | <b>0.07</b>      |
| Lab - 04        | 0.0512         | <b>-0.03</b>     | 0.0658         | <b>-0.25</b>     | 0.0524         | <b>0.43</b>      | 0.115          | <b>-0.73</b>     | 0.0523         | <b>-0.33</b>     | 0.0478         | <b>0.16</b>      | 0.0145         | <b>-1.22</b>     |
| Lab - 05        | 0.0516         | <b>0.03</b>      | 0.0662         | <b>-0.21</b>     | 0.0507         | <b>0.20</b>      | 0.140          | <b>0.55</b>      | 0.0537         | <b>-0.16</b>     | 0.0496         | <b>0.41</b>      | 0.0190         | <b>0.44</b>      |
| Lab - 06        | 0.0522         | <b>0.10</b>      | 0.0682         | <b>-0.01</b>     | 0.0470         | <b>-0.30</b>     | 0.136          | <b>0.36</b>      | 0.0552         | <b>0.02</b>      | 0.0460         | <b>-0.10</b>     | 0.0182         | <b>0.15</b>      |
| Lab - 07        | 0.0510         | <b>-0.05</b>     | 0.0652         | <b>-0.30</b>     | 0.0404         | <b>-1.19</b>     | 0.120          | <b>-0.47</b>     | 0.0581         | <b>0.37</b>      | 0.0477         | <b>0.14</b>      | 0.0188         | <b>0.37</b>      |
| Lab - 08        | 0.0527         | <b>0.17</b>      | 0.0680         | <b>-0.03</b>     | 0.0517         | <b>0.34</b>      | 0.135          | <b>0.30</b>      | 0.0557         | <b>0.08</b>      | 0.0487         | <b>0.29</b>      | 0.0185         | <b>0.26</b>      |
| Lab - 09        | 0.0490         | <b>-0.31</b>     | 0.0620         | <b>-0.62</b>     | 0.0480         | <b>-0.16</b>     | 0.128          | <b>-0.06</b>     | 0.0470         | <b>-0.96</b>     | 0.0440         | <b>-0.39</b>     | 0.0180         | <b>0.07</b>      |
| Lab - 10        | 0.0547         | <b>0.43</b>      | 0.0672         | <b>-0.11</b>     | 0.0480         | <b>-0.16</b>     | 0.144          | <b>0.77</b>      | NA             | NA               | NA             | NA               | 0.0192         | <b>0.52</b>      |
| Lab - 11        | 0.0494         | <b>-0.26</b>     | 0.0677         | <b>-0.06</b>     | 0.0527         | <b>0.47</b>      | 0.126          | <b>-0.16</b>     | 0.0497         | <b>-0.64</b>     | 0.0469         | <b>0.03</b>      | 0.0165         | <b>-0.48</b>     |
| Lab - 12        | 0.0550         | <b>0.47</b>      | 0.0749         | <b>0.65</b>      | 0.0682         | <b>2.57</b>      | 0.138          | <b>0.46</b>      | 0.0633         | <b>1.00</b>      | 0.0472         | <b>0.07</b>      | 0.0153         | <b>-0.93</b>     |
| Lab - 13        | 0.0479         | <b>-0.45</b>     | 0.0648         | <b>-0.34</b>     | 0.0472         | <b>-0.27</b>     | 0.128          | <b>-0.06</b>     | 0.0515         | <b>-0.42</b>     | 0.0465         | <b>-0.03</b>     | 0.0160         | <b>-0.67</b>     |
| Lab - 14        | 0.0511         | <b>-0.04</b>     | 0.0665         | <b>-0.18</b>     | 0.0405         | <b>-1.18</b>     | 0.142          | <b>0.66</b>      | 0.0524         | <b>-0.31</b>     | 0.0461         | <b>-0.09</b>     | 0.0167         | <b>-0.41</b>     |
| Lab - 15        | 0.0495         | <b>-0.25</b>     | 0.0628         | <b>-0.54</b>     | 0.0395         | <b>-1.31</b>     | 0.120          | <b>-0.47</b>     | 0.0554         | <b>0.05</b>      | 0.0476         | <b>0.13</b>      | 0.0190         | <b>0.44</b>      |
| Lab - 16        | 0.0487         | <b>-0.35</b>     | 0.0745         | <b>0.61</b>      | 0.0553         | <b>0.82</b>      | 0.132          | <b>0.15</b>      | 0.0543         | <b>-0.08</b>     | 0.0430         | <b>-0.53</b>     | 0.0184         | <b>0.22</b>      |

**भारतीय अंगूर अनुसंधान केन्द्र, पुणे**  
**ICAR-National Research Centre for Grapes, Pune**

| Laboratory code | Azoxystrobin   |                  | Buprofezin     |                  | Carbendazim    |                  | Chlorpyriphos  |                  | Difenoconazole |                  | Dimethomorph   |                  | Fluopyram      |                  |
|-----------------|----------------|------------------|----------------|------------------|----------------|------------------|----------------|------------------|----------------|------------------|----------------|------------------|----------------|------------------|
|                 | Assigned value | Robust Std. Dev. |
|                 | 0.0514         | 0.0077           | 0.0683         | 0.0102           | 0.0492         | 0.0074           | 0.129          | 0.0194           | 0.0550         | 0.0083           | 0.0467         | 0.0070           | 0.0178         | 0.0027           |
|                 | Conc. mg/kg    | z-score          |
| Lab - 17        | 0.0503         | -0.14            | 0.0704         | 0.21             | 0.0466         | -0.35            | 0.130          | 0.05             | 0.0525         | -0.30            | 0.0440         | -0.39            | 0.0179         | 0.04             |
| Lab - 18        | 0.0520         | 0.08             | 0.0750         | 0.66             | 0.0898         | 5.49             | 0.121          | -0.42            | 0.0580         | 0.36             | 0.0511         | 0.63             | 0.0250         | 2.67             |
| Lab - 19        | 0.0642         | 1.66             | 0.0684         | 0.01             | 0.0739         | 3.34             | 0.120          | -0.46            | 0.0734         | 2.22             | 0.0711         | 3.49             | 0.0242         | 2.37             |
| Lab - 20        | 0.0521         | 0.09             | 0.0705         | 0.22             | 0.0526         | 0.46             | 0.130          | 0.05             | 0.0541         | -0.11            | 0.0480         | 0.19             | 0.0180         | 0.07             |
| Lab - 21        | 0.0521         | 0.09             | 0.0711         | 0.27             | 0.0520         | 0.38             | 0.128          | -0.06            | 0.0541         | -0.11            | 0.0475         | 0.11             | 0.0179         | 0.04             |
| Lab - 22        | 0.0514         | 0.00             | 0.0661         | -0.22            | 0.0287         | -2.77            | 0.125          | -0.21            | 0.0517         | -0.40            | 0.0488         | 0.30             | 0.0163         | -0.56            |
| Lab - 23        | 0.0529         | 0.19             | 0.0717         | 0.33             | 0.0501         | 0.12             | 0.130          | 0.05             | 0.0545         | -0.06            | 0.0475         | 0.11             | 0.0179         | 0.04             |
| Lab - 24        | 0.0470         | -0.57            | 0.0650         | -0.32            | 0.0450         | -0.57            | 0.125          | -0.21            | 0.0520         | -0.36            | 0.0450         | -0.24            | 0.0160         | -0.67            |
| Lab - 25        | 0.0466         | -0.62            | 0.0699         | 0.16             | 0.0534         | 0.57             | 0.138          | 0.46             | 0.0555         | 0.06             | 0.0416         | -0.73            | 0.0181         | 0.11             |
| Lab - 26        | NA             | NA               | NA             | NA               | NA             | NA               | 0.108          | -1.10            | NA             | NA               | NA             | NA               | NA             | NA               |
| Lab - 27        | 0.0542         | 0.36             | 0.0699         | 0.16             | 0.0497         | 0.07             | 0.137          | 0.41             | 0.0531         | -0.23            | 0.0455         | -0.17            | 0.0183         | 0.19             |
| Lab - 28        | 0.0510         | -0.05            | 0.0710         | 0.26             | 0.0540         | 0.65             | 0.142          | 0.68             | 0.0547         | -0.04            | 0.0453         | -0.20            | 0.0193         | 0.56             |
| Lab - 29        | 0.0528         | 0.18             | 0.0713         | 0.29             | 0.0494         | 0.03             | 0.130          | 0.05             | 0.0528         | -0.27            | 0.0487         | 0.29             | 0.0190         | 0.44             |
| Lab - 30        | 0.0512         | -0.03            | 0.0646         | -0.36            | 0.0412         | -1.08            | 0.120          | -0.47            | 0.0564         | 0.17             | 0.0488         | 0.30             | 0.0186         | 0.30             |
| Lab - 31        | 0.0524         | 0.13             | 0.0689         | 0.06             | 0.0364         | -1.73            | 0.139          | 0.51             | 0.0533         | -0.20            | 0.0404         | -0.90            | 0.0169         | -0.33            |
| Lab - 32        | 0.0439         | -0.97            | 0.0646         | -0.36            | 0.0501         | 0.12             | 0.121          | -0.42            | 0.0569         | 0.23             | 0.0480         | 0.19             | 0.0154         | -0.89            |
| Lab - 33        | 0.0582         | 0.88             | 0.0733         | 0.49             | 0.0507         | 0.20             | 0.130          | 0.05             | 0.0584         | 0.41             | 0.0508         | 0.59             | 0.0183         | 0.19             |
| Lab - 34        | 0.0497         | -0.22            | 0.0696         | 0.13             | 0.0790         | 4.03             | 0.132          | 0.15             | 0.0611         | 0.73             | 0.0498         | 0.44             | 0.0130         | -1.78            |
| Lab - 35        | 0.0540         | 0.34             | 0.0630         | -0.52            | 0.0530         | 0.51             | 0.132          | 0.15             | 0.0540         | -0.12            | 0.0440         | -0.39            | 0.0160         | -0.67            |
| Lab - 36        | 0.0528         | 0.18             | 0.0722         | 0.38             | 0.0482         | -0.14            | 0.125          | -0.21            | 0.0593         | 0.52             | 0.0414         | -0.76            | 0.0168         | -0.37            |




**भारतीय अंगूर अनुसंधान केन्द्र, पुणे**  
**ICAR-National Research Centre for Grapes, Pune**

| Laboratory code | Azoxystrobin   |                  | Buprofezin     |                  | Carbendazim    |                  | Chlorpyriphos  |                  | Difenconazole  |                  | Dimethomorph   |                  | Fluopyram      |                  |
|-----------------|----------------|------------------|----------------|------------------|----------------|------------------|----------------|------------------|----------------|------------------|----------------|------------------|----------------|------------------|
|                 | Assigned value | Robust Std. Dev. |
|                 | 0.0514         | 0.0077           | 0.0683         | 0.0102           | 0.0492         | 0.0074           | 0.129          | 0.0194           | 0.0550         | 0.0083           | 0.0467         | 0.0070           | 0.0178         | 0.0027           |
|                 | Conc. mg/kg    | z-score          |
| Lab - 37        | 0.0531         | <b>0.22</b>      | 0.0654         | <b>-0.28</b>     | 0.0481         | <b>-0.15</b>     | 0.138          | <b>0.46</b>      | 0.0524         | <b>-0.31</b>     | 0.0450         | <b>-0.24</b>     | 0.0171         | <b>-0.26</b>     |
| Lab - 38        | 0.0540         | <b>0.34</b>      | 0.0724         | <b>0.40</b>      | 0.0363         | <b>-1.74</b>     | 0.112          | <b>-0.88</b>     | 0.0544         | <b>-0.07</b>     | 0.0450         | <b>-0.24</b>     | 0.0164         | <b>-0.52</b>     |
| Lab - 39        | 0.0606         | <b>1.19</b>      | 0.0747         | <b>0.63</b>      | 0.0518         | <b>0.35</b>      | 0.131          | <b>0.10</b>      | 0.0559         | <b>0.11</b>      | 0.0501         | <b>0.49</b>      | 0.0247         | <b>2.56</b>      |
| Lab - 40        | 0.0506         | <b>-0.10</b>     | 0.0696         | <b>0.13</b>      | 0.0476         | <b>-0.22</b>     | 0.128          | <b>-0.06</b>     | 0.0551         | <b>0.01</b>      | 0.0490         | <b>0.33</b>      | 0.0183         | <b>0.19</b>      |
| Lab - 41        | 0.0546         | <b>0.42</b>      | 0.0584         | <b>-0.97</b>     | 0.0491         | <b>-0.01</b>     | 0.129          | <b>-0.01</b>     | 0.0597         | <b>0.57</b>      | 0.0423         | <b>-0.63</b>     | NA             | NA               |
| Lab - 42        | 0.0497         | <b>-0.22</b>     | 0.0663         | <b>-0.20</b>     | 0.0499         | <b>0.09</b>      | 0.133          | <b>0.20</b>      | 0.0550         | <b>0.00</b>      | 0.0456         | <b>-0.16</b>     | 0.0173         | <b>-0.19</b>     |
| Lab - 43        | 0.0451         | <b>-0.82</b>     | 0.0687         | <b>0.04</b>      | 0.0566         | <b>1.00</b>      | 0.120          | <b>-0.47</b>     | 0.0541         | <b>-0.11</b>     | 0.0526         | <b>0.84</b>      | 0.0173         | <b>-0.19</b>     |
| Lab - 44        | 0.0550         | <b>0.47</b>      | 0.0630         | <b>-0.52</b>     | 0.0425         | <b>-0.91</b>     | 0.131          | <b>0.08</b>      | 0.0660         | <b>1.33</b>      | 0.0502         | <b>0.50</b>      | 0.0176         | <b>-0.07</b>     |
| Lab - 45        | 0.0483         | <b>-0.40</b>     | 0.0605         | <b>-0.76</b>     | 0.0403         | <b>-1.20</b>     | 0.136          | <b>0.36</b>      | 0.0469         | <b>-0.98</b>     | 0.0432         | <b>-0.50</b>     | 0.0153         | <b>-0.93</b>     |
| Lab - 46        | 0.0455         | <b>-0.77</b>     | 0.0727         | <b>0.43</b>      | 0.0436         | <b>-0.76</b>     | 0.113          | <b>-0.83</b>     | 0.0560         | <b>0.12</b>      | 0.0438         | <b>-0.41</b>     | 0.0200         | <b>0.81</b>      |

$|z| \leq 2$  Acceptable,  $2 < |z| \leq 3$  Questionable,  $|z| > 3$  Unacceptable

z-score mentioned in Black: Acceptable; Blue: Questionable; Red: Unacceptable

**भारतीय अनुप्रयोग अंगूर अनुसंधान केन्द्र, पुणे**  
**ICAR-National Research Centre for Grapes, Pune**

**Table 2b: Preliminary report showing analyte specific assigned values, robust standard deviation, reported concentration and z-score of the participating laboratories**

| Laboratory code | Fluxapyroxod   |                  | Imidacloprid   |                  | Kresoxim methyl |                  | Mandipropamid  |                  | Metrafenone    |                  | Myclobutanil   |                  | Pyaclostrobin  |                  |
|-----------------|----------------|------------------|----------------|------------------|-----------------|------------------|----------------|------------------|----------------|------------------|----------------|------------------|----------------|------------------|
|                 | Assigned value | Robust Std. Dev. | Assigned value | Robust Std. Dev. | Assigned value  | Robust Std. Dev. | Assigned value | Robust Std. Dev. | Assigned value | Robust Std. Dev. | Assigned value | Robust Std. Dev. | Assigned value | Robust Std. Dev. |
|                 | Conc. mg/kg    | z-score          | Conc. mg/kg    | z-score          | Conc. mg/kg     | z-score          | Conc. mg/kg    | z-score          | Conc. mg/kg    | z-score          | Conc. mg/kg    | z-score          | Conc. mg/kg    | z-score          |
| Lab - 01        | 0.0209         | <b>0.45</b>      | 0.0590         | <b>-0.09</b>     | 0.0410          | <b>-0.32</b>     | 0.0682         | <b>0.31</b>      | 0.0194         | <b>0.14</b>      | 0.0180         | <b>0.11</b>      | 0.0152         | <b>-0.38</b>     |
| Lab - 02        | 0.0203         | <b>0.24</b>      | 0.0561         | <b>-0.41</b>     | 0.0434          | <b>0.05</b>      | 0.0654         | <b>0.02</b>      | 0.0179         | <b>-0.38</b>     | 0.0156         | <b>-0.78</b>     | 0.0153         | <b>-0.33</b>     |
| Lab - 03        | 0.0210         | <b>0.48</b>      | 0.0590         | <b>-0.09</b>     | 0.0440          | <b>0.14</b>      | 0.0650         | <b>-0.02</b>     | 0.0190         | <b>0.00</b>      | 0.0180         | <b>0.11</b>      | 0.0140         | <b>-0.88</b>     |
| Lab - 04        | 0.0194         | <b>-0.07</b>     | 0.0558         | <b>-0.44</b>     | 0.0416          | <b>-0.23</b>     | 0.0654         | <b>0.02</b>      | 0.0181         | <b>-0.31</b>     | 0.0177         | <b>0.00</b>      | 0.0143         | <b>-0.75</b>     |
| Lab - 05        | 0.0186         | <b>-0.34</b>     | 0.0645         | <b>0.52</b>      | 0.0451          | <b>0.31</b>      | 0.0657         | <b>0.05</b>      | 0.0190         | <b>0.00</b>      | 0.0188         | <b>0.41</b>      | 0.0165         | <b>0.17</b>      |
| Lab - 06        | 0.0194         | <b>-0.07</b>     | 0.0624         | <b>0.29</b>      | 0.0442          | <b>0.17</b>      | 0.0642         | <b>-0.10</b>     | 0.0192         | <b>0.07</b>      | 0.0182         | <b>0.19</b>      | 0.0174         | <b>0.54</b>      |
| Lab - 07        | 0.0198         | <b>0.07</b>      | 0.0556         | <b>-0.47</b>     | 0.0404          | <b>-0.42</b>     | 0.0637         | <b>-0.15</b>     | 0.0203         | <b>0.45</b>      | 0.0193         | <b>0.59</b>      | 0.0195         | <b>1.42</b>      |
| Lab - 08        | 0.0200         | <b>0.14</b>      | 0.0637         | <b>0.43</b>      | 0.0464          | <b>0.51</b>      | 0.0673         | <b>0.21</b>      | 0.0200         | <b>0.34</b>      | 0.0177         | <b>0.00</b>      | 0.0157         | <b>-0.17</b>     |
| Lab - 09        | 0.0160         | <b>-1.24</b>     | 0.0560         | <b>-0.42</b>     | 0.0440          | <b>0.14</b>      | 0.0640         | <b>-0.12</b>     | 0.0180         | <b>-0.34</b>     | 0.0160         | <b>-0.63</b>     | 0.0150         | <b>-0.46</b>     |
| Lab - 10        | 0.0225         | <b>1.00</b>      | 0.0564         | <b>-0.38</b>     | 0.0465          | <b>0.52</b>      | 0.0614         | <b>-0.39</b>     | 0.0228         | <b>1.31</b>      | 0.0176         | <b>-0.04</b>     | NA             | NA               |
| Lab - 11        | 0.0179         | <b>-0.59</b>     | 0.0592         | <b>-0.07</b>     | 0.0419          | <b>-0.18</b>     | 0.0622         | <b>-0.31</b>     | 0.0186         | <b>-0.14</b>     | 0.0178         | <b>0.04</b>      | 0.0143         | <b>-0.75</b>     |
| Lab - 12        | 0.0182         | <b>-0.48</b>     | 0.0649         | <b>0.57</b>      | 0.0459          | <b>0.43</b>      | 0.0689         | <b>0.38</b>      | 0.0213         | <b>0.79</b>      | 0.0191         | <b>0.52</b>      | 0.0162         | <b>0.04</b>      |
| Lab - 13        | 0.0188         | <b>-0.28</b>     | 0.0601         | <b>0.03</b>      | 0.0425          | <b>-0.09</b>     | 0.0638         | <b>-0.14</b>     | 0.0179         | <b>-0.38</b>     | 0.0170         | <b>-0.26</b>     | 0.0147         | <b>-0.58</b>     |
| Lab - 14        | 0.0175         | <b>-0.72</b>     | 0.0605         | <b>0.08</b>      | 0.0420          | <b>-0.17</b>     | 0.0616         | <b>-0.37</b>     | 0.0169         | <b>-0.72</b>     | 0.0169         | <b>-0.30</b>     | 0.0142         | <b>-0.79</b>     |
| Lab - 15        | 0.0192         | <b>-0.14</b>     | 0.0544         | <b>-0.60</b>     | 0.0415          | <b>-0.25</b>     | 0.0627         | <b>-0.26</b>     | 0.0200         | <b>0.34</b>      | 0.0192         | <b>0.56</b>      | 0.0185         | <b>1.00</b>      |
| Lab - 16        | 0.0225         | <b>1.00</b>      | 0.0635         | <b>0.41</b>      | 0.0437          | <b>0.09</b>      | 0.0642         | <b>-0.10</b>     | 0.0198         | <b>0.28</b>      | 0.0181         | <b>0.15</b>      | 0.0184         | <b>0.96</b>      |
| Lab - 17        | 0.0189         | <b>-0.24</b>     | 0.0596         | <b>-0.02</b>     | 0.0418          | <b>-0.20</b>     | 0.0634         | <b>-0.18</b>     | 0.0180         | <b>-0.34</b>     | 0.0173         | <b>-0.15</b>     | 0.0160         | <b>-0.04</b>     |

**भारतीय अंगूर अनुसंधान केन्द्र, पुणे**  
**ICAR-National Research Centre for Grapes, Pune**

| Laboratory code | Fluxapyroxod   |                  | Imidacloprid   |                  | Kresoxim methyl |                  | Mandipropamid  |                  | Metrafenone    |                  | Myclobutanil   |                  | Pyaclostrobin  |                  |
|-----------------|----------------|------------------|----------------|------------------|-----------------|------------------|----------------|------------------|----------------|------------------|----------------|------------------|----------------|------------------|
|                 | Assigned value | Robust Std. Dev. | Assigned value | Robust Std. Dev. | Assigned value  | Robust Std. Dev. | Assigned value | Robust Std. Dev. | Assigned value | Robust Std. Dev. | Assigned value | Robust Std. Dev. | Assigned value | Robust Std. Dev. |
|                 | Conc. mg/kg    | z-score          | Conc. mg/kg    | z-score          | Conc. mg/kg     | z-score          | Conc. mg/kg    | z-score          | Conc. mg/kg    | z-score          | Conc. mg/kg    | z-score          | Conc. mg/kg    | z-score          |
| Lab - 18        | 0.0252         | <b>1.93</b>      | 0.0598         | <b>0.00</b>      | 0.0549          | <b>1.82</b>      | 0.0793         | <b>1.44</b>      | 0.0256         | <b>2.28</b>      | 0.0202         | <b>0.93</b>      | 0.0198         | <b>1.54</b>      |
| Lab - 19        | 0.0244         | <b>1.66</b>      | 0.0699         | <b>1.12</b>      | 0.0532          | <b>1.55</b>      | 0.0841         | <b>1.93</b>      | 0.0184         | <b>-0.21</b>     | 0.0171         | <b>-0.22</b>     | 0.0244         | <b>3.46</b>      |
| Lab - 20        | 0.0200         | <b>0.14</b>      | 0.0601         | <b>0.03</b>      | 0.0451          | <b>0.31</b>      | 0.0693         | <b>0.42</b>      | 0.0204         | <b>0.48</b>      | 0.0172         | <b>-0.19</b>     | 0.0164         | <b>0.13</b>      |
| Lab - 21        | 0.0192         | <b>-0.14</b>     | 0.0594         | <b>-0.04</b>     | 0.0451          | <b>0.31</b>      | 0.0702         | <b>0.51</b>      | 0.0198         | <b>0.28</b>      | 0.0181         | <b>0.15</b>      | 0.0166         | <b>0.21</b>      |
| Lab - 22        | 0.0182         | <b>-0.48</b>     | 0.0574         | <b>-0.27</b>     | 0.0413          | <b>-0.28</b>     | 0.0587         | <b>-0.66</b>     | 0.0186         | <b>-0.14</b>     | 0.0177         | <b>-0.00</b>     | 0.0152         | <b>-0.38</b>     |
| Lab - 23        | 0.0188         | <b>-0.28</b>     | 0.0614         | <b>0.18</b>      | 0.0440          | <b>0.14</b>      | 0.0682         | <b>0.31</b>      | 0.0193         | <b>0.10</b>      | 0.0177         | <b>0.00</b>      | 0.0160         | <b>-0.04</b>     |
| Lab - 24        | 0.0180         | <b>-0.55</b>     | 0.0600         | <b>0.02</b>      | 0.0390          | <b>-0.63</b>     | 0.0630         | <b>-0.22</b>     | 0.0170         | <b>-0.69</b>     | 0.0170         | <b>-0.26</b>     | 0.0140         | <b>-0.88</b>     |
| Lab - 25        | 0.0198         | <b>0.07</b>      | 0.0614         | <b>0.18</b>      | 0.0399          | <b>-0.49</b>     | 0.0671         | <b>0.19</b>      | 0.0191         | <b>0.03</b>      | 0.0170         | <b>-0.26</b>     | 0.0159         | <b>-0.08</b>     |
| Lab - 26        | NA             | NA               | NA             | NA               | NA              | NA               | NA             | NA               | NA             | NA               | NA             | NA               | NA             | NA               |
| Lab - 27        | 0.0186         | <b>-0.34</b>     | 0.0601         | <b>0.03</b>      | 0.0429          | <b>-0.03</b>     | 0.0646         | <b>-0.06</b>     | 0.0192         | <b>0.07</b>      | 0.0171         | <b>-0.22</b>     | 0.0181         | <b>0.83</b>      |
| Lab - 28        | 0.0213         | <b>0.59</b>      | 0.0590         | <b>-0.09</b>     | 0.0410          | <b>-0.32</b>     | 0.0650         | <b>-0.02</b>     | 0.0207         | <b>0.59</b>      | 0.0193         | <b>0.59</b>      | 0.0163         | <b>0.08</b>      |
| Lab - 29        | 0.0201         | <b>0.17</b>      | 0.0594         | <b>-0.04</b>     | 0.0424          | <b>-0.11</b>     | 0.0713         | <b>0.62</b>      | 0.0181         | <b>-0.31</b>     | 0.0158         | <b>-0.70</b>     | 0.0154         | <b>-0.29</b>     |
| Lab - 30        | 0.0202         | <b>0.21</b>      | 0.0545         | <b>-0.59</b>     | 0.0410          | <b>-0.32</b>     | 0.0650         | <b>-0.02</b>     | 0.0204         | <b>0.48</b>      | 0.0198         | <b>0.78</b>      | 0.0191         | <b>1.25</b>      |
| Lab - 31        | 0.0173         | <b>-0.79</b>     | 0.0565         | <b>-0.37</b>     | 0.0399          | <b>-0.49</b>     | 0.0639         | <b>-0.13</b>     | 0.0177         | <b>-0.45</b>     | 0.0155         | <b>-0.81</b>     | 0.0138         | <b>-0.96</b>     |
| Lab - 32        | 0.0195         | <b>-0.03</b>     | 0.0545         | <b>-0.59</b>     | 0.0451          | <b>0.31</b>      | 0.0586         | <b>-0.67</b>     | 0.0163         | <b>-0.93</b>     | 0.0168         | <b>-0.33</b>     | 0.0155         | <b>-0.25</b>     |
| Lab - 33        | 0.0192         | <b>-0.14</b>     | 0.0604         | <b>0.07</b>      | 0.0491          | <b>0.92</b>      | 0.0690         | <b>0.39</b>      | 0.0203         | <b>0.45</b>      | 0.0162         | <b>-0.56</b>     | 0.0180         | <b>0.79</b>      |
| Lab - 34        | 0.0222         | <b>0.90</b>      | 0.0635         | <b>0.41</b>      | 0.0479          | <b>0.74</b>      | 0.0640         | <b>-0.12</b>     | 0.0114         | <b>-2.62</b>     | 0.0202         | <b>0.93</b>      | 0.0158         | <b>-0.12</b>     |
| Lab - 35        | 0.0170         | <b>-0.90</b>     | 0.0570         | <b>-0.31</b>     | 0.0470          | <b>0.60</b>      | 0.0660         | <b>0.08</b>      | 0.0180         | <b>-0.34</b>     | 0.0180         | <b>0.11</b>      | 0.0160         | <b>-0.04</b>     |
| Lab - 36        | 0.0203         | <b>0.24</b>      | 0.0644         | <b>0.51</b>      | 0.0418          | <b>-0.20</b>     | 0.0633         | <b>-0.19</b>     | 0.0209         | <b>0.66</b>      | 0.0175         | <b>-0.07</b>     | 0.0179         | <b>0.75</b>      |
| Lab - 37        | 0.0192         | <b>-0.14</b>     | 0.0592         | <b>-0.07</b>     | 0.0421          | <b>-0.15</b>     | 0.0643         | <b>-0.09</b>     | 0.0194         | <b>0.14</b>      | 0.0173         | <b>-0.15</b>     | 0.0154         | <b>-0.29</b>     |

**भारतीय अंगूर अनुसंधान केन्द्र, पुणे**  
**ICAR-National Research Centre for Grapes, Pune**

| Laboratory code | Fluxapyroxod   |                  | Imidacloprid   |                  | Kresoxim methyl |                  | Mandipropamid  |                  | Metrafenone    |                  | Myclobutanil   |                  | Pyaclostrobin  |                  |
|-----------------|----------------|------------------|----------------|------------------|-----------------|------------------|----------------|------------------|----------------|------------------|----------------|------------------|----------------|------------------|
|                 | Assigned value | Robust Std. Dev. | Assigned value | Robust Std. Dev. | Assigned value  | Robust Std. Dev. | Assigned value | Robust Std. Dev. | Assigned value | Robust Std. Dev. | Assigned value | Robust Std. Dev. | Assigned value | Robust Std. Dev. |
|                 | Conc. mg/kg    | z-score          | Conc. mg/kg    | z-score          | Conc. mg/kg     | z-score          | Conc. mg/kg    | z-score          | Conc. mg/kg    | z-score          | Conc. mg/kg    | z-score          | Conc. mg/kg    | z-score          |
| Lab - 38        | 0.0197         | <b>0.03</b>      | 0.0630         | <b>0.36</b>      | 0.0402          | <b>-0.45</b>     | 0.0653         | <b>0.01</b>      | 0.0229         | <b>1.34</b>      | 0.0183         | <b>0.22</b>      | 0.0181         | <b>0.83</b>      |
| Lab - 39        | 0.0256         | <b>2.07</b>      | 0.0706         | <b>1.20</b>      | 0.0420          | <b>-0.17</b>     | 0.0777         | <b>1.28</b>      | 0.0153         | <b>-1.28</b>     | 0.0117         | <b>-2.22</b>     | 0.0162         | <b>0.04</b>      |
| Lab - 40        | 0.0194         | <b>-0.07</b>     | 0.0548         | <b>-0.56</b>     | 0.0444          | <b>0.20</b>      | 0.0686         | <b>0.35</b>      | 0.0189         | <b>-0.03</b>     | 0.0182         | <b>0.19</b>      | 0.0147         | <b>-0.58</b>     |
| Lab - 41        | NA             | NA               | 0.0619         | <b>0.23</b>      | 0.0431          | <b>0.00</b>      | 0.0607         | <b>-0.46</b>     | NA             | NA               | 0.0184         | <b>0.26</b>      | 0.0159         | <b>-0.08</b>     |
| Lab - 42        | 0.0190         | <b>-0.21</b>     | 0.0614         | <b>0.18</b>      | 0.0426          | <b>-0.08</b>     | 0.0627         | <b>-0.26</b>     | 0.0192         | <b>0.07</b>      | 0.0167         | <b>-0.37</b>     | 0.0161         | <b>0.00</b>      |
| Lab - 43        | 0.0185         | <b>-0.38</b>     | 0.0616         | <b>0.20</b>      | 0.0427          | <b>-0.06</b>     | 0.0683         | <b>0.32</b>      | 0.0197         | <b>0.24</b>      | 0.0222         | <b>1.67</b>      | 0.0164         | <b>0.13</b>      |
| Lab - 44        | 0.0233         | <b>1.28</b>      | 0.0650         | <b>0.58</b>      | 0.0392          | <b>-0.60</b>     | 0.0600         | <b>-0.53</b>     | 0.0197         | <b>0.24</b>      | 0.0180         | <b>0.11</b>      | 0.0147         | <b>-0.58</b>     |
| Lab - 45        | 0.0172         | <b>-0.83</b>     | 0.0557         | <b>-0.46</b>     | 0.0362          | <b>-1.06</b>     | 0.0663         | <b>0.11</b>      | 0.0180         | <b>-0.34</b>     | 0.0169         | <b>-0.30</b>     | 0.0145         | <b>-0.67</b>     |
| Lab - 46        | 0.0212         | <b>0.55</b>      | 0.0586         | <b>-0.13</b>     | 0.0457          | <b>0.40</b>      | 0.0603         | <b>-0.50</b>     | 0.0168         | <b>-0.76</b>     | 0.0162         | <b>-0.56</b>     | 0.0164         | <b>0.13</b>      |

$|z| \leq 2$  Acceptable,  $2 < |z| \leq 3$  Questionable,  $|z| > 3$  Unacceptable

z-score mentioned in Black: Acceptable; Blue: Questionable; Red: Unacceptable

\*\*\*\*\*End of Report\*\*\*\*\*